


SWINBURNE UNIVERSITY OF TECHNOLOGY

TNE20002 / TNE70003

Topic 6 DHCP V1.0





# All devices

# PCs, switches, IPhones, printers, servers etc

need an IP address

to connect to a network





#### Static IP addresses

 Devices such as routers, servers, printers, photocopiers etc, need an address that will not change

Static address assignment is required





# Dynamic IP addresses

- PCs, Laptops in an organization often change locations, physically and logically:
  - Dynamic address assignment is required
  - Can use any IP address within the range of the Host IP addresses in the subnet.





# DHCP

# Address Allocation

MAD!




#### **DHCP Address Allocation - MAD**



#### Automatic

#### Manual



Network devices that remain in the same place (logically and physically) are assigned static IP addresses.

#### Dynamic



Network devices that are added, moved or changed (physical and logical) need new addresses. Manual configuration is unwieldy.



# DHCP - Address Allocation Techniques - MAD



#### Manual

The IP address for the client is pre-allocated by the administrator and

DHCP conveys the IP address to the client.



# DHCP - Address Allocation Techniques - MAD



#### **Automatic**

DHCP selects from an address pool, automatically assigns

a permanent IP address to a client with no lease period.



# DHCP - Address Allocation Techniques - MAD



# **Dynamic**

DHCP selects from an address pool

and leases the IP address to the client for a limited period of time.





# **DHCP** Operation

DORA

Discover, Offer,


Request, Acknowledge

Client Action



# DHCP Operation – Four Messages - DORA






DHCP messages in the order they are transmitted



# DHCP Operation – Four Messages - DORA





DHCP messages in the order they are transmitted



# DHCP Operation – Obtaining a Lease – Discover



# 1. DHCP Discover (to Server)

Client (PC) broadcasts DHCPDISCOVER message

DHCPDISCOVER finds DHCP server(s)

Uses layer 2 (FF:FF:FF:FF:FF:FF) and layer 3
 broadcast addresses to communicate with server(s)



# DHCP Operation – Obtaining a Lease – Offer



# 2. DHCP Offer (to Client)


- DHCP Server
  - finds available IP address to lease
  - creates and ARP entry in its ARP table consisting of the MAC address of requesting host and the leased IP address
  - Sends DHCPOFFER message to Client

 Unicast using server's layer 2 MAC address as source and client's layer 2 MAC address as destination



# DHCP Operation - Messages Discover and Offer






**Offer Details** 

#### Here is Your Configuration:

- IP Address: 192.204.18.7
- Subnet Mask: 255.255.255.0
- Default Gateway: 192.204.18.1
- DNS Servers: 192.204.18.8, 192.204.18.9
- Lease Time: 5 days

# DHCP Operation – Messages Discover and Offer





# DHCP – Obtaining a Lease – Request



#### 3. DHCP Request (to Server)

Client broadcasts DHCPREQUEST message, two purposes:

Requests IP lease information be verified to ensure assignment is still valid

 Serves as a binding acceptance notice to the selected server and an implicit decline to any other DHCP servers that may have given the client an offer



# DHCP – Obtaining a Lease – Acknowledge




# 4. DHCP ACK (to Client)

Server replies with unicast DHCPACK



# DHCP Operation – DORA Messages 1, 2, 3 and 4





- DHCP client broadcasts DHCPDISCOVER packet on local subnet
- DHCP servers send OFFER packet with lease information
- DHCP client selects lease and broadcasts DHCPREQUEST packet
- Selected DHCP server sends DHCP ACK packet

#### **DHCP – Client Action**



 Client checks IP address is not a Duplicate within Subnet

 Client sends ARP request (does any host within the subnet have this IP address?) using new IP address

 If no other hosts in subnet reply, the IP address is not a duplicate, hence it can use the IP address



# Configuring DHCP



Router(config) #ip dhcp pool pool-name1

Specify the DHCP pool

Router (dhcp-config) #network ip-address mask

Specify the range of addresses in the pool

- Creates an IP DHCP pool, and gives it a name
- Multiple DHCP pools can be created on one server
- Specify the IP range of addresses using an IP network address and mask

The network statement enables DHCP on any router interfaces belonging to that network.

- The router will act as a DHCP server on that interface.
- It is also the pool of addresses that the DHCP server will use.
- Pool NaMe (vs nAmE) is case sensitive



# Configuring DHCP



```
Router (config) \# ip dhcp excluded-address ip-address [end-ip-address]
```

```
Router (config) #ip dhcp excluded-address 172.16.12.1 172.16.12.10
Router (config) #ip dhcp excluded-address 172.16.12.254
```

```
Router (config) #ip dhcp pool swonet12
Router (dhcp-config) #network 172.16.12.0 255.255.255.0
Router (dhcp-config) #default-router 172.16.12.254
Router (dhcp-config) #dns-server 172.16.1 2
Router (dhcp-config) #netbios-name-server 172.16.1.3
Router (dhcp-config) #domain-name foo.com
```

- The ip dhep excluded-address command configures the router to exclude an individual address or range of addresses when assigning addresses to clients.
- IP configuration values such as the default gateway can be set.



# Configuring DHCP – Manual Allocation



Manually allocating an IP address to a printer, photocopier etc

- Router(config)# ip dhcp pool subnet12
- Router(dhcp-config)# host 172.16.12.5 255.255.255.0
- Router(dhcp-config)# client-identifier < unique-identifier >

- The unique-identifier of the client the printer, is specified in dotted hexadecimal notation, for example, 01b7.0813.8811.66, where 01 represents the Ethernet media type, followed by client's MAC address
- When this printer's DHCP Client requests an IP address it will receive 172.16.12.5



# Configuring a Cisco Router as a DHCP Server



The Enabling the DHCP service:

☐ To enable the service:

Router(config) #service dhcp

☐ To disable the service:

Router(config) #no service dhcp



# Configuring DHCP - Options



Command	Description
<pre>network network-number [mask   prefix-length]</pre>	Specifies the subnet network number and mask of the DHCP address pool. The prefix length specifies the number of bits that compromise the address prefix. The prefix is an alternative way of specifying the network mask of the client. The prefix length must be preceded by a forward slash (/).
default-router address [address2address8]	Specifies the IP address of the default gateway for a DHCP client. Although one address is required, up to eight addresses can be specified in one command line.
<pre>dns-server address [address2address8]</pre>	Specifies the IP address of a DNS server that is available to a DHCP client. Although one address is required, up to eight addresses can be specified in one command line.
netbios-name-server address [address2address8]	Specifies the NetBios WINS server that is available to a Microsoft DHCP client. Although one address is required, up to eight addresses can be specified in one command line.
domain-name name	Specifies the domain name for the client.
<pre>lease {days [hours] [minutes]   infinite}</pre>	Specifies the duration of the lease. The default is a one-day lease.



# Verifying and Troubleshooting DHCP



```
Router#show ip dhcp binding

IP address Hardware address Lease expiration Type

172.16.12.11 0100.10a4.97f4.6d Mar 02 1993 12:38 AM Automatic

Router#
```

# Router#debug ip dhcp server events Router# 00:22:53: DHCPD:checking for expired leases. 00:22:23: DHCPD: assigned IP address 172.16.13.11 to client 0100.10a4.97f4.6d 00:22:49: DHCPD:retured 172.16.13.11 to address pool remote. 00:22:59: DHCPD: assigned IP address 172.16.13.11 to client 0100.10a497f4.6d.



# Verifying and Troubleshooting DHCP



show ip dhcp server statistics

show ip dhcp pool



# **DHCP** Relay



The

**DHCP** Server

is in a


different

subnet



### DHCP Relay – DHCP Server in a different subnet






#### DHCP Relay – DHCP Server in a different subnet



#### DHCP Relay





# DHCP Explained | Step by Step - YouTube



